

SecurCAM INSTRUCTION MANUAL



WiFi Pan/Tilt Indoor Camera

WiFi Dome Indoor Camera




WiFi Bullet Outdoor Camera


DEVICE INSTALLATION & CONFIGURATION

This manual is suitable for various types of cameras. (The appearance may be different and the details are subject to the receipt. This manual is only for the installation instructions).


1. WIFI PAN/TILT INDOOR CAMERA



2. WIFI BULLET OUTDOOR CAMERA



3. WIFI DOME INDOOR CAMERA



DESCRIPTION

- 1. Photosensitive** The Sensor collects the ambient light & switches ON the IR LEDs when the lux level falls below 3 lux.
- 2. Reset button** During working state of the device, press the Reset button for 3-5 seconds to restore the factory default setting. A voice prompt broadcast will confirm the setting.
- 3. SD card slot** Insert TF card for recording and playback the video.
- 4. DC power supply** Power input.
- 5. Network port** Connect the LAN cable and check the current device status.
- 6. Indicator light** Indicator light flashes once for 1 sec on hotspot mode.

APP DOWNLOAD AND INSTALLATION


Download the 'Halonix SecurCAM' App from Apple App store or Google Play store to your smartphone or tablet.

Note: The app requires iOS version 9.0 or above and Android version 5.0 or above.

ACCOUNT LOGIN

Login with the registered mobile number or Email ID, enter password, and click on the 'Confirm' button.


For account login existing users, enter the email/phone number and password and for new users register the email/phone number.




DEVICE ADDITION PROCESS

1. Add by Wi-Fi mode (optional)


1. After the Halonix SecurCam is turned ON, wait for the indicator light to flash slowly. Connect to the Wi-Fi in the phone settings and enter the password.




2. Open the APP and click on the '+' icon on the upper right corner to enter the scan code interface.



3. Scan the QR code on the device.




4. On the search device interface, click 'Add'.




5. To view and use with Wi-Fi or other networks, please select 'Remote View'. If there is no network, connect to the camera at close range and select 'Direct Connection'.

2. Add by Remote View


1. Click 'Remote View' Choose the Wi-Fi device that needs to be connected with. Enter the password and proceed to the next step.



2. Please wait patiently while the device gets configured.




3. Once the device is added successfully, please set a name and password for the device.




3. Add by Direct Connection

1. To add the device select 'Direct Connection'. Set the name and password for the device once added successfully.




Note: The Direct Connection needs to be connected to the device hotspot to preview the device screen normally.


2. Connect to the hotspot in the phone settings and enter the password.




3. When the QR code of the device cannot be found (or the scan code is unsuccessful) Click 'Other ways to add' on the scan code interface.




4. Select the standalone camera option. The subsequent adding process is similar to that of 'Remote View' and 'Direct Connection' method.




4. Add by Wired Connection
Method 1
1. Power ON the device, connect it to a router with a network cable. Scan the QR code on the device and click 'Add'.
2. It will be added successfully after setting of the name and password for the device.




Method 2
1. Select 'Add by ID/IP' in 'Other ways to add'.



2. Enter the device ID and password, and click 'complete' in the upper right corner to add successfully.



Method 3
1. When the mobile phone and the device are on the same network, select LAN, scan in 'Other ways to add'.
2. After searching the device, click 'Add'. Enter the device ID and password to complete the addition.



CORPORATE OFFICE

Halonix Technologies Pvt. Ltd.

B - 31, Phase-2, Noida, (U.P.) - 201305. Tel: +91 - 120 - 4756100,

Fax: +91 - 120 - 4756101

REGIONAL OFFICES

EAST

Halonix Technologies Pvt. Ltd.

67B Ballygunge Circular Road, Ballygunge Park Tower, 9th Floor,

Kolkata - 700019, Tel: +91 - 033 - 40081849

WEST

Halonix Technologies Pvt. Ltd.

The Affairs Office No. 1402, 14th floor

Plot No. 9, Sector 17, Sanpada Navi Mumbai, Thane - 400705

Tel: +91 - 022 - 35120050

SOUTH

Halonix Technologies Pvt. Ltd.

No.6, "Legacy" 1st Floor, Convent Road, Richmond Town

Bengaluru - 560025, Tel: +91 - 080 - 41125296

For more information/customer feedback, contact customer care executive
Toll Free No.: 1800-103-6564 | E-mail: customercare@halonix.co.in | Website: www.halonix.co.in